

Electrochemical cell and Applications of EMF MEASUREMENTS

Electrochemical cell-

- ▶ An electrochemical cell is a device capable of either generating electrical energy from chemical reactions (Chemical energy) or using electrical energy to cause chemical reactions.

Electrical energy \rightleftharpoons Chemical energy

- ▶ Electrochemical cell are two types-

(1) **Electrolytic cell:** which convert electrical energy to chemical reactions.

e.g. electrolysis of aqueous solution NaCl by passing electricity.

(2) **Galvanic cells or Voltaic cell:** which generate an electric current by using chemical reactions.

e.g. Daniel cell

Parts of Electrochemical cell-

- ▶ **Vessel:** which contains all electrochemical system.
- ▶ **Electrolyte:** in the form of electrolytic solutions into which two electrodes are submerged.
- ▶ **Electrodes:** usually metal strips/wires connected by an electrically conducting wire.
- ▶ **Anode:** electrode where oxidation takes place.
- ▶ **Cathode:** electrode where reduction takes place.
- ▶ **Salt Bridge:** U-shaped tube that contains a gel permeated with a solution of an inert electrolyte. Present in galvanic cell for maintaining electro neutrality of two half cell's electrolytic solutions.





Figure: Electrolytic cell




Figure: Galvanic cell




Figure: Chemical reactions in Daniel cell




Figure: Chemical reactions in Daniel cell

Galvanic cell:

- ▶ A galvanic cell is also referred to as a voltaic cell. The common household battery is an example of a galvanic cell.
- ▶ Galvanic cell composed of two half cells or two electrode-
 - (i) Left hand electrode or Anode:
Zn electrode submerged in ZnSO_4 aqueous solution
 - (ii) Right hand electrode or Cathode:
Cu electrode submerged in CuSO_4 aqueous solution
- ▶ The electricity or EMF is generated due to half cell reactions taking place at different cell
- ▶ The combination of two half reactions whose addition gives the overall cell reaction or net cell reaction:


- At anode (Left hand electrode):



- At cathode (Right hand electrode):



- Net overall cell reaction can be obtained by adding oxidation and reduction half cell reactions



- EMF of this galvanic cell is given by Nernst equation as follows:

$$E = E^0 + \frac{RT}{nF} \ln \frac{[\text{Cu}^{+2}]}{[\text{Zn}^{+2}]} \quad \text{---- Eq. no. (1)}$$

$$E = E^0 + \frac{2.303RT}{nF} \log_{10} \frac{[\text{Cu}^{+2}]}{[\text{Zn}^{+2}]} \quad \text{---- Eq. no. (2)}$$

Where, E^0 = Standard EMF of Galvanic cell = 1.10 V

On putting the values of Temperature (T) = 25°C (298.15K), Value of gas constant, R= 8.31 J/K/mol, Faraday, F= 96500 Coulomb

$$E = E^0 + \frac{0.0591}{2} \log_{10} \frac{[Cu^{+2}]}{[Zn^{+2}]} \quad \text{---- Eq. no. (3)}$$

Cell notation for Electrochemical cell:

This is the way of representation of electrochemical cell by combination of symbols.

- ▶ A galvanic cell is generally represented by putting a vertical line between species which are in direct contact e.g. metal and electrolyte solution
- ▶ Species which are not in direct contact are represented by putting a double vertical line between them e.g. the two electrolytes connected by a salt bridge.
- ▶ Anode is denoted on the left and the cathode on the right



Cell notation for Galvanic cell:



Electromotive Force (EMF)-

- ▶ The potential difference between the two electrodes of a galvanic cell is called the cell potential and is measured in volts.
- ▶ By latest consideration, the cell potential is the difference between the electrode potentials (reduction potentials) of the cathode and anode.
- ▶ It is called the cell electromotive force (EMF) of the cell when no current is drawn through the cell.
- ▶ So, EMF of cell is determined by techniques or devices which draw no current from the cell during measurements.
- ▶ By observing cell notation , $E_{\text{cell}} = E_{\text{right}} - E_{\text{left}}$ or $E_{\text{cell}} = E_{\text{cathode}} - E_{\text{anode}}$
- ▶ According to latest convention of IUPAC all the electrode potential all expressed in terms of reduction potential with respect to standard hydrogen electrode (S.H.E.)

- ▶ When all the standard electrode potential (in terms of reduction potential) are arranged from higher to lower value then this is termed as Electrochemical series.
- ▶ Electrochemical series is given on next page.
- ▶ There are so many applications of this Electrochemical series.
- ▶ Out of these applications, some one can calculate standard EMF (E_0) of a particular cell alternatively.
- ▶ For example the standard EMF of Galvanic cell



$$E_{\text{cell}}^0 = E_{\text{cathode}}^0 - E_{\text{anode}}^0 = 0.34 - (-0.76) = 1.10 \text{ Volt}$$

Table 1 The standard electrode potentials at 298 K

Ions are present as aqueous species and H₂O as liquid; gases and solids are shown by g and s.

Reaction (Oxidised form + ne ⁻)	→ Reduced form)	E° / V
F ₂ (g) + 2e ⁻	→ 2F ⁻	2.87
Co ³⁺ + e ⁻	→ Co ²⁺	1.81
H ₂ O ₂ + 2H ⁺ + 2e ⁻	→ 2H ₂ O	1.78
MnO ₄ ⁻ + 8H ⁺ + 5e ⁻	→ Mn ²⁺ + 4H ₂ O	1.51
Au ³⁺ + 3e ⁻	→ Au(s)	1.40
Cl ₂ (g) + 2e ⁻	→ 2Cl ⁻	1.36
Cr ₂ O ₇ ²⁻ + 14H ⁺ + 6e ⁻	→ 2Cr ³⁺ + 7H ₂ O	1.33
O ₂ (g) + 4H ⁺ + 4e ⁻	→ 2H ₂ O	1.23
MnO ₂ (s) + 4H ⁺ + 2e ⁻	→ Mn ²⁺ + 2H ₂ O	1.23
Br ₂ + 2e ⁻	→ 2Br ⁻	1.09
NO ₃ ⁻ + 4H ⁺ + 3e ⁻	→ NO(g) + 2H ₂ O	0.97
2Hg ²⁺ + 2e ⁻	→ Hg ₂ ²⁺	0.92
Ag ⁺ + e ⁻	→ Ag(s)	0.80
Fe ³⁺ + e ⁻	→ Fe ²⁺	0.77
O ₂ (g) + 2H ⁺ + 2e ⁻	→ H ₂ O ₂	0.68
I ₂ + 2e ⁻	→ 2I ⁻	0.54
Cu ⁺ + e ⁻	→ Cu(s)	0.52
Cu ²⁺ + 2e ⁻	→ Cu(s)	0.34
AgCl(s) + e ⁻	→ Ag(s) + Cl ⁻	0.22
AgBr(s) + e ⁻	→ Ag(s) + Br ⁻	0.10
2H ⁺ + 2e ⁻	→ H ₂ (g)	0.00
Pb ²⁺ + 2e ⁻	→ Pb(s)	-0.13
Sn ²⁺ + 2e ⁻	→ Sn(s)	-0.14
Ni ²⁺ + 2e ⁻	→ Ni(s)	-0.25
Fe ²⁺ + 2e ⁻	→ Fe(s)	-0.44
Cr ³⁺ + 3e ⁻	→ Cr(s)	-0.74
Zn ²⁺ + 2e ⁻	→ Zn(s)	-0.76
2H ₂ O + 2e ⁻	→ H ₂ (g) + 2OH ⁻ (aq)	-0.83
Al ³⁺ + 3e ⁻	→ Al(s)	-1.66
Mg ²⁺ + 2e ⁻	→ Mg(s)	-2.36
Na ⁺ + e ⁻	→ Na(s)	-2.71
Ca ²⁺ + 2e ⁻	→ Ca(s)	-2.87
K ⁺ + e ⁻	→ K(s)	-2.93
Li ⁺ + e ⁻	→ Li(s)	-3.05

Increasing strength of oxidising agent

Increasing strength of reducing agent


1. A negative E° means that the redox couple is a stronger reducing agent than the H⁺/H₂ couple.
2. A positive E° means that the redox couple is a weaker reducing agent than the H⁺/H₂ couple.

A positive E° means that the redox couple is a weaker reducing agent than the H⁺/H₂ couple.
A negative E° means that the redox couple is a stronger reducing agent than the H⁺/H₂ couple.


Figure: Electrochemical Series

Li ⁺ + e ⁻	→ Li(s)	-3.05
K ⁺ + e ⁻	→ K(s)	-2.93
Ca ²⁺ + 2e ⁻	→ Ca(s)	-2.87

- **Example 1:** Find the standard electrode potential of the cell using electrochemical series; $\text{Cu}_{(s)} | \text{Cu}^{2+} || \text{Cl}^- | \text{AgCl}_{(s)} | \text{Ag}_{(s)}$ and predict the direction of electron flow when the two electrodes are connected.
- **Solution.** The reactions corresponding to this cell will be:



Net Reaction can be obtained by adding anode and cathode reaction



Value of E^0_{cathode} and E^0_{anode} can be obtained by using electrochemical series.

$$E^0_{\text{cell}} = E^0_{\text{cathode}} - E^0_{\text{anode}} = (0.22 - 0.34) \text{ Volt} = -0.12 \text{ V}$$

Applications of EMF Measurements-

(i) Determination of Equilibrium Constant

- ▶ By measurement of the standard Emf of the cell, E° , some one enable to evaluate the equilibrium constant for the electrode reaction.
- ▶ The relation between the standard free energy change(G^0) and the equilibrium constant(K) is:

$$G^0 = -RT \ln K \quad \text{---- Eq. no. (4)}$$

- ▶ Standard free energy is related to the standard electrode potential by relation:

$$G^0 = - n F E^0 \quad \text{----- Eq. no. (5)}$$

From Eq. no. (1) and (2)

$$E^0 = (RT/nF) \ln K \quad \text{----- Eq. no. (6)}$$

$$E^0 = (2.303RT/nF) \log_{10} K$$

at T =298K, R= 8.13J/K/mol, F=96500 Coulomb Eq. no. (3) becomes


$$E^0 = (0.0591/n) \log_{10} K \quad \text{----- Eq. no. (7)}$$

For determining equilibrium constant (K) of particular type of equilibrium reaction some one has:

- ❖ To design a electrochemical cell in which net cell reaction is same as equilibrium reaction.
- ❖ To determine EMF of above cell.
- ❖ To calculate equilibrium constant by Eq. no. (7)

(ii) Determination of Solubility Products-

- ▶ Solubility product of sparingly soluble salt $MX_{(s)}$ viz. AgCl etc. can be determined.
- ▶ Sparingly soluble salt is type of equilibrium constant.
- ▶ Let us suppose a sparingly soluble salt $MX_{(s)}$ in equilibrium with its ions in a saturated solution



$$K_{SP} = a_M^+ \cdot a_X^-$$

- ▶ The above cell reaction is the cell reaction for following cell



The half cell reaction are:



$$E_{\text{cell}}^0 = E_{\text{right}}^0 - E_{\text{left}}^0 \quad \text{----- Eq. no. (8)}$$

► By considering K_{SP} as equilibrium constant and using eq. no.(4), (5), (6)

$$nFE_{\text{cell}}^0 = 2.303RT \log_{10} K_{\text{SP}}$$

$$\log_{10} K_{\text{SP}} = nFE_{\text{cell}}^0 / 2.303 RT$$

$$\text{At } 25^{\circ} \text{C} \quad \log_{10} K_{\text{SP}} = nE_{\text{cell}}^0 / 0.0591 \quad \text{----- Eq. no. (9)}$$

E_{cell}^0 can be determined by using eq. no. (8) and electrochemical series.

So, by using eq. no. (9) some one can determine K_{SP}

(iii) Determination of pH-

- ▶ For this half cell (Hydrogen electrode) is setup with the test solution as electrolyte.
- ▶ EMF of the cell depends on the concentration of H^+ or pH of solution.
- ▶ Principle behind this method is to determine the activity of H^+ or the concentration of H^+ .


$$\text{Since, } \text{pH} = -\log H^+$$

- ▶ Conc./ activity of H^+ can be determined by setting a cell in which one of the electrodes is reversible to hydrogen ions.
- ▶ In practice the EMF OF hydrogen electrode is combined with another reference electrode such as standard hydrogen electrode (SHE)
or a saturated calomel electrode (SCE) or any other reference electrode. ..

- ▶ By using S.H.E. cell notation of considered cell can be given as follows:



- ▶ For single hydrogen electrode $\text{Pt}/\text{H}_2 (1\text{atm}) / \text{H}^+$, the electrode reaction is:



$$E_{\text{right}} = E_{\text{SHE}}^0 + \frac{RT}{nF} \ln \frac{[\text{H}^+]}{[\text{P}_{\text{H}_2}]^{1/2}}$$

$$E_{\text{right}} = E_{\text{SHE}}^0 + \frac{2.303RT}{nF} \log_{10} \frac{[\text{H}^+]}{[\text{P}_{\text{H}_2}]^{1/2}}$$

- ▶ Since, $E_{\text{SHE}}^0 = 0$ and $\text{P}_{\text{H}_2}^{1/2} = 1$

$$E_{\text{right}} = 0.0591 \log_{10} [\text{H}^+]$$

$$E_{\text{right}} = -0.0591 \text{ pH} \quad \text{---- Eq. no. (10)}$$

▶

- ▶ Since, EMF (E_{cell}) of cell constructed for pH determination can be given by

$$E_{\text{cell}} = E_{\text{right}} - E_{\text{left}}$$

- ▶ E_{left} is S.H.E. whose Electrode potential is arbitrarily assigned equal to zero by IUPAC.

- ▶ So, $E_{\text{cell}} = E_{\text{right}} - 0$

$$E_{\text{cell}} = E_{\text{right}} \quad \text{---- Eq. no. (11)}$$

- ▶ From eq. no. (11) and (12)

$$E_{\text{cell}} = -0.0591 \text{ pH}$$

$$pH = \frac{E_{\text{cell}}}{0.0591}$$

- ▶ E_{cell} is determined by no current drawing based measurement (viz. potentiometer) and hence pH can be determined.

► Exercise 1

The standard EMF of the Daniel cell involving the cell reaction $\text{Zn}_{(s)} + \text{Cu}^{2+} \rightleftharpoons \text{Zn}^{2+} + \text{Cu}_{(s)}$ is 1.10 Volts. Calculate the equilibrium constant of the cell reaction at 25°C

► Exercise 2

Calculate equilibrium constant for the following electrochemical cell

$\text{Zn}/\text{Zn}^{2+} // \text{Fe}^{3+}, \text{Fe}^{2+} / \text{Pt}$; Whose standard EMF is 1.534V, the overall cell reaction is $\text{Fe}^{3+} + 1/2\text{Zn} = \text{Fe}^{2+} + 1/2\text{Zn}^{2+}$

► Exercise 3

Find the standard electrode potential of the cell using electrochemical series; $\text{Cu}_{(s)} | \text{Cu}^{2+} | \text{Cl}^- || \text{AgCl}_{(s)} | \text{Ag}_{(s)}$ and predict the direction of electron flow when the two electrodes are connected.

References-

- ▶ P C Jain , M. Jain, Engineering Chemistry, Dhanpat Rai Publications.
- ▶ S. S. Dara, A Text Book of Engineering Chemistry, S. Chand & Company.
- ▶ Shashi Chawla, Engineering Chemistry, Dhanpat Rai Publications.
- ▶ <https://quizlet.com/312668465/galvanic-cells-flash-cards/>

THANK YOU